

U Series Firmware Update Guide (Mac)

Copyright(C) 2016 ZOOM Corporation. All Rights Reserved.

●Zoom Corporation does not bear liability for any damages or third-party claims arising from the use of the software, whether directly or indirectly. Unauthorized redistribution, sale, leasing, renting, alteration, or reverse engineering of the software is prohibited. Features and specifications of the software and the contents of the documentation may be changed in future without notice.

• Macintosh®, Mac®, Mac OS® and OS X® are trademarks or registered trademarks of Apple Inc.
• Intel®, Intel® Core™ are trademarks or registered trademarks of Intel Corporation in the U.S. and/or other countries.
Note: Other Product names, registered trademarks and company names in this document are the property of their respective companies.
Note: All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

The illustrations in these instructions might differ from actual screens.

Contents

1. Introduction	2
2. System Requirements	2
Precautions	2
3. Updating the firmware	3

1. Introduction

Thank you very much for downloading the firmware update application for the U-44/U-24/U-22.

This document explains how to update the firmware for the U-44/U-24/U-22.

2. System Requirements

OS : Mac® OS X® 10.9.5 (or later)

CPU: Intel® Core™ i3 or faster

USB: USB 3.0/USB 2.0


(Operation is not guaranteed when used with USB hubs or expansion cards.)

Precautions



- 1) **Log in to your Mac computer using an account with administrator privileges.**
- 2) **Before starting this application, shut down all other applications that are running. In addition, if any MIDI or audio devices are connected by USB cable to the computer you are using, disconnect them all.**

3. Updating the firmware

- 3.1. Connect the U-44/U-24/U-22 and the Mac using a USB cable. Then, turn the U-44/U-24/U-22 power on.
- 3.2. Double-click the firmware update application icon to launch it.
After launching, a window that looks like this appears.




- 3.3. In both the “Input Device” and “Output Device” fields, click the field to open a list of MIDI devices and select “U-XX ZOOM U-XX Reserved Port”.
If nothing is shown in the fields, click **[Rescan Device]** button.



3.4. Click the [**Version Check**] button to check the firmware version.

3.5. Click the [**Execute**] button to start the firmware update. The progress of the firmware update appears as a bar like this.



Do not disconnect the USB cable while the firmware is being updated.

3.6. When the firmware update completes, it will appear as follows.



Click the [**OK**] button and [**Exit**] button to close the firmware update application. Then, turn the U-44/U-24/U-22 power off.

This completes the firmware update.