The system software version is shown on the display at startup.

You can always download the latest system software for free at the web site shown below.

http://www.zoom.co.jp/

## Version 2.00

- Released as following function updates in November 2019
- 1. Added a function that enables the user to select the LOOPER position from Pre/Post.
- 2. Changed the RHYTHM screen.
  - \*For details please refer to the most recent Operation Manual.

## Version 1.10

- Released as following bug fix in May 2019
- 1. USB connection is sometimes disabled after a certain period of time.

## Version 1.00

Released as mass production in March 2019