

Android devices confirmed to work with the L6

As of January 2025, the operation confirmed Android Devices are as follows.

Brand	Model	OS Ver.	Cubasis	Spotify for Podcasters	Skype	YouTube	BandLab ^{*1}
Google	Pixel 3	12	●	●	●	●	●
	Pixel 8	14	●	●	●	●	●
Huawei	P30 Pro	9 (EMUI 9.1.0)	●	●	●	●	●
	P30 lite	10 (EMUI 10.0.0)	●	●	●	●	X
OPPO	A73	11	●	●	●	●	●
SAMSUNG	Galaxy Note10+	12	●	●	●	●	●
	Galaxy S21 Ultra 5G (Snapdragon)	14 (One UI 6.1)	●	●	●	●	●
	Galaxy S21 Ultra 5G (Exynos)	14 (One UI 6.1)	X	●	X	●	X
	Galaxy S24	14 (One UI 6.1)	●	●	X	●	●
	Galaxy A21	11 (One UI 3.1)	●	●	X	●	●
	Galaxy A32 5G	13	●	●	X	●	●
	Galaxy A41	11	X	●	X	●	X
	Galaxy A51	13 (One UI 5.1)	●	●	X	●	●
SHARP	AQUOS sense3 lite	11	X	●	●	●	X
	AQUOS sense4 basic	12	●	●	●	●	●
SONY	Xperia Ace III	14	●	●	●	●	●
	Xperia 10 II	11	●	●	X	●	●
Xiaomi	Mi 11 Ultra	13 (MIUI 14.0.13)	●	●	●	●	●
	Redmi Note 9S	11 (MIUI 12.5.4)	●	●	●	●	●

*1 : The MIDI CC numbers used for adjusting L6 channel 3/4 levels are the same as those used by BandLab for starting and stopping playback/recording.

Use the ZOOM L6 Editor app to edit MIDI CC# Mapping and change the LEVEL CH3/CH4 MIDI CC numbers.

Note: This information shows the results of operation confirmation conducted by our company.

This is not a guarantee that no issues will occur with the above devices.