

Handy Guitar Lab for MS-80IR+

for iOS

Version 1.0

Operation Manual



This document cannot be displayed properly on black-and-white displays.

Contents

Contents	2
Introduction	4
Copyrights	4
Using with iPhones and iPads	5
Installing Handy Guitar Lab for MS-80IR+	5
Connecting to the MS-80IR+	5
Handy Guitar Lab for MS-80IR+ Overview	7
Using the Effects Screen to manage effects	8
Effects Screen Overview	8
Deleting/Restoring Effects	9
Sorting Effects	10
Filtering Effects	11
Viewing Effect Properties	12
Using the Patch Memory Screen to manage patch memories	13
Patch Memory Screen Overview	13
Reordering a Patch Memory	14
Editing Patch Memory Names and Comments	15
Backing Up a Single Patch Memory	16
Backing Up Multiple Patch Memories	17
Restoring backed up patch memories to the unit	18
Restoring a Back Up to the Device	19
Sharing a Patch Memory	20
Importing a Patch Memory	21
Using the Editor Screen to edit patch memories	22
Editor Screen Overview	22
Selecting a Patch Memory for Editing	23
Editing a Patch Memory Name	24
Turning effects on/off	25
Adjusting Effect Parameters	26
Changing Effects	27
Adding Effects	28
Deleting Effects	29
Reordering Effects	30
Adjusting Tempo	31
Changing the R signal output position	32
Saving a Patch Memory	33

Reverting a Change	34
Using favorite effect settings (clips)	35
■ Creating Clips	35
■ Adding a Clip to a Patch Memory	36
■ Editing Clip Names	37
■ Deleting a Clip	38
Creating a New Patch Memory	39
Erasing a Patch Memory	40
Tuning Your Instrument	41
Use Import IR to load IR data	42
Import IR Screen Overview	42
Loading IR data	43
Edit the IR name	44
Deleting IR data	45
Using IRs	46
Using the News Screen to review updated information	48
News Screen Overview	48
Select and View News Updates	49
Download Patch Memory Updates	50
Loading effects that are newly available into the unit	51
Viewing a variety of information on the About Screen	52
About Screen Overview	52
Changing the language setting	53

Introduction

Handy Guitar Lab for MS-80IR+ is a remote control application specifically designed for the ZOOM MS-80IR+ MultiStomp. Whether you are creating and editing patch memories, managing effects and patch memories or backing up patch memories, this app allows you to operate a MS-80IR+ from an iOS compatible mobile device. This manual does not explain the operation of the MS-80IR+. See the MS-80IR+ Operation Manual for detailed information about all its functions.

Accessibility for the Visually Impaired

Handy Guitar Lab for MS-80IR+ supports iPhone VoiceOver. With VoiceOver enabled, people with visual impairments can use the app to control the MS-80IR+.

Copyrights

iPhone, iPad, iPadOS and Lightning are trademarks of Apple Inc.

App Store is a service mark of Apple Inc.

iOS is a trademark or registered trademark of Cisco Systems, Inc. in the USA and other countries and is used under license.

USBType-C is a trademark of the USB Implementers Forum.

Product names, registered trademarks and company names in this document are the property of their respective companies. All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

Using with iPhones and iPads

Installing Handy Guitar Lab for MS-80IR+

- 1. Open the App Store on the iPhone and search for Handy Guitar Lab for MS-80IR+.
- **2.** Tap "GET" on the Handy Guitar Lab for MS-80IR+ screen.

 This will install Handy Guitar Lab for MS-80IR+ on the device.




HINT

· This can also be installed and used on iPads.

Connecting to the MS-80IR+

Connect the MS-80IR+ to your iPhone using a USB-C to USB-A cable and an Apple Lightning to USB 3 Camera Adapter.




NOTE

- · Please make sure the USB cable being used supports data transfer.
- For iOS / iPadOS devices with connectors, please connect using a USB-C to USB-C cable.


- 2. Turn on the MS-80IR+.
- Tap the Handy Guitar Lab for MS-80IR+ app icon. Handy Guitar Lab for MS-80IR+ will launch.




4. Tap "Download" to download the latest MS-80IR+ data.



5 The MS-80IR+ and Handy Guitar Lab for MS-80IR+ will sync data and connect.



Handy Guitar Lab for MS-80IR+ Overview



Effects Screen

View the effects installed on the device (with sort and filter tools), add/remove them, and download new effects from ZOOM.

Patch Memory Screen

View, select and organize patch memories on the device, create backups, import and share patch memories from friends.

Import IR

Impulse response data, including data you already have and from third parties, can be loaded.

News Screen

View and download the latest patch memory updates for your device from ZOOM.

Editor Screen

Choose from hundreds of effects and amps to create and edit patch memories. Bypass, Re-order, change, delete effects and adjust individual parameters to create your custom tones. Save your favorite effect combos to the clipboard to quickly recall them later.



Using the Effects Screen to manage effects



Effects Screen Overview



- MS-80IR+ Connected Device
- **Used memory indicator**
- 3 Effect Poor

Effect Pool / New Effect Indicator

If there are new effects, the number available will be shown.

- **Filter Effects button**
- **Sort Effects button**
- **6** Installed Effect

Displays effect name, icon, description, power usage, use count. Tap to view full details.

Favorite button

Tap this to set the effect as a favorite. Favorite effects can be shown together using the Sort Effects button.

- **Effect Screen button**
- **Patch Memory Screen button**
- **Editor Screen button**
- Import IR Screen button
- **News Screen button**

Deleting/Restoring Effects



Long-tap any effect.



2 Tap "Delete from Device 🗓 ".



3. Tap "Delete" to confirm.



4. The deleted effect displays the restore icon.

To restore a deleted effect, tap the & icon.



Sorting Effects

You can select the order in which effects are listed. By default, effects sorted ascending by category.



1 Tap the the button open the sort list.



2. Tap the method to sort by.

You can choose to sort ascending " \wedge " or descending " \vee " by tapping the sort method again.


Effect Category	Sort in category order.
Effect Name	Sort in alphabetical order.
Power	Sort by power usage.
Use	Show by the number of times used in patch memories on the device.
Favorites	Sort with favorites first.

Filtering Effects


By default, the all effects are displayed.



1 Tap the button.



Tap the effect category you would like to display. Tap done.




3 The list displays only the effects in the filtered category.

Viewing Effect Properties



1 Tap any effect row.



2. The Effect property screen appears.


From this screen you can view the effect name, description, version, power usage, effect count, and descriptions for each parameter of the effect.

You can also add/remove to/from favorites or delete/restore the effect.

Using the Patch Memory Screen to manage patch memories



Patch Memory Screen Overview



- ① MS-80|R+ Connected Device
- 2 Pool Pool button
- 3 Select Select mode button
- 4 Patch memory Entry


Displays the patch memory number, name, description. Long tap to view and edit details.

(5) Current patch indicator


the patch that is actively playing on the device.

- 6 Patch Memory Reorder icon
- **(7)** Effect Screen button
- 8 Patch Memory Screen button
- 9 Editor Screen button
- 10 Import IR button
- 1 News Screen button


Reordering a Patch Memory



1 Tap and hold the on the patch memory you want to move.



2. Drag the patch memory up or down in the list to reorder it.



3. Release the tap to place the patch memory in the new location.

Editing Patch Memory Names and Comments



1 Long-tap any patch memory on the Patch screen.



2. Tap "Edit Patch Info "" to display the on-screen keyboard for editing.



Tap the name or comment fields to edit them.



4. Tap 🔞 to finish editing.

NOTE

- · Valid characters and symbols: $!\% \& '+, -.= _ (space) A Z, a z, 0 9.$
- · Patch memory names can have a maximum of 28 characters.


Backing Up a Single Patch Memory



1 Long-tap any patch memory to back up.



2. Tap "Save to Pool 🗥 ".



3. The patch memory is added to the Pool.

Backing Up Multiple Patch Memories




1 Tap Select on the Patch Memory screen.




2 Tap one or more ot to select them.



Tap save to save selected patch memories to the Pool.



4 Selected patch memories are saved to a Patch Group (folder) and added to the Pool.



Restoring backed up patch memories to the unit



1 Tap "Select" on the Pool screen.



2 Tap one or more to select them.



Tap copy to save selected patch memories to the Patch Pool.



4. Tap on the Copy to Device screen to select the destination of the first patch memory. Tap Done.


NOTE

Tap Select All to select every patch memory in the folder.

Restoring a Back Up to the Device



1 Tap "Pool" on the Patch Memory screen.



2. Long-tap a back up folder.



3 Tap "Copy to Device ①". The back up has been restored to the device.



The message disappears after restoring completes.


Sharing a Patch Memory



Tap Select on the Patch Memory screen.



2 Tap one or more to select the patch memories you wish to share.



Tap the button to open the device sharing screen.



4. From the mobile device sharing screen, choose how you want to share the patch memory file.

Importing a Patch Memory


Patch memory files can be imported from iPhone.



Tap Pool on the Patch Memory screen.




2 Tap the Import button.



3 Tap to select the patch memory files (.zptc) that you want to import.

Tap Open.




4. The imported patch memories appear in the Pool.


Using the Editor Screen to edit patch memories



Editor Screen Overview



■ Toolbar



- 1 001 KRAMPUS Current patch memory
- Patch memory select button
- Save patch memory button
- Effect on/off button
- **Current effect indicator** shows which effect parameters are displayed.
- **(6**) Effect parameter knob

- Add effect button
- **Delete effect button** (8)
- Change effect button
- Clip tool button (10)
- (11) **Clipboard button**
- **Tuner button**

Selecting a Patch Memory for Editing


1 Tap the button in the navigation bar.



2 Tap . The current patch memory is displayed to its left.



3 Tap the patch memory you want to edit.



Tap the New button to create a blank patch memory.

Editing a Patch Memory Name

1 Tap the patch memory name in the Editor.



2 The on-screen keyboard appears. Edit the name.



3 When done, tap outside the field to finish editing.

NOTE

- 'Valid characters and symbols: ! % & ' + , . = $_$ (space) A Z, a z, 0 9.
- · Patch memory names can have a maximum of 28 characters.

Turning effects on/off


1 Tap the indicator above an effect to turn it on/off.




When on, it lights red. When off, it is unlit.

Adjusting Effect Parameters


1 Tap an effect to show/hide its parameters.



2 Tap and swipe right/left to change values.



3 For precise parameter changes, double-tap a parameter knob to display the parameter popup.



Changing Effects

1 Tap the button in the toolbar.



2 Tap the effect you wish to change.



3 Select a different effect from the effect type list. Then tap "OK".



Tap the CBack button to select effects from other effect categories.


4. The original effect is replaced with the new effect.



Tap to finish replacing effects.

Adding Effects

1 Tap the button in the toolbar.




Tap and drag it to the position where you want to add an effect. Then, tap



3 Tap the category of the effect that you want to add.



4. Select the effect that you want to add from the effect type list and tap "OK".



Deleting Effects

1 Tap the button in the toolbar.



2 Tap the effect you wish to delete.



3. Delete the effect.




Tap to finish deleting effects.

Reordering Effects

You can drag and drop to re-order the effects in the effect chain, at any time, except when the editor is in delete or clip mode.


1 Tap and hold the effect you want to move.



2 Drag the effect right or left along the chain to re-order it.




3. Release to drop the effect in the desired location.



Adjusting Tempo

1 Add a BPM module.


The BPM module is in the TOOL category (\rightarrow Adding effects).



2. Tap the BPM Module in the chain.



3 The tempo pop up appears where you can tap the tempo or adjust it.



HINT


· Each patch memory can only have one BPM module.

Changing the R signal output position

1 Tap and hold .



2 Drag left or right to change position.



3 Release your finger at the desired position to confirm the change.



Saving a Patch Memory

1 Tap the Save button at the top of the Editor screen.




2 Tap the oto select the patch memory you want to overwrite. Tap "OK".



The confirmation popup is displayed. Tap Cancel or Save.






Reverting a Change

If you want to discard the changes you made to the patch memory, you can use the Revert function.

1 After you make a change, the Revert button appears in the toolbar. Tap it to discard your changes.



2 Tap Previous to discard your changes.



3. The patch memory returns to the previous state.



NOTE

· If you tap "Factory", the original factory patch memory for that patch memory number will be restored.

Using favorite effect settings (clips)

■ Creating Clips

Clips store effect on/off states and parameter setting values. You can create your own clips, store them on the Clipboard, and use them to quickly build new patch memories.

1 Tap the button in the toolbar.



2 Select the effect to clip.



3 Tap the Add to Clipboard button. The clip is added to the Clipboard.



■ Adding a Clip to a Patch Memory

Clips store effect on/off states and parameter setting values. You can use to quickly build new patch memories.



1 Tap clipboard in the toolbar. The clips will appear below the effect chain.



2 Tap-hold then drag clip onto the effect chain.




3. Release to drop the clip when it is in the desired position.
The effects from the clip are added to the patch memory.

■ Editing Clip Names

1 In Clipboard mode, long-tap a clip.



2. Tap "Edit Name III".



3 Edit the name using the on-screen keyboard. Tap return or on the screen when you are finished editing.



■ Deleting a Clip


1 In Clipboard mode, long-tap a clip.



2. Tap "Delete ⊞ ".




3 The Clip is removed from the Clipboard.



Creating a New Patch Memory

1 Tap the button at the top of the Editor screen.



2 Tap the New button at the top of the Select a Patch screen.

The app creates a new patch memory.



3 Tap the Back button.



4. Edit the new patch memory in the editor.



Erasing a Patch Memory

1 Tap the button at the top of the Editor screen.



2 Tap the button to erase the patch memory.



3 Tap "Yes" to confirm or "No" to cancel the operation.



4. The erased patch memory retains its patch memory number and is named "Empty".



Tuning Your Instrument


1 Tap the button in the navigation bar.



2. Tap the Juner button in the toolbar.




3 The Tuner popup appears where you can tune your instrument.



Use Import IR to load IR data



Import IR Screen Overview



- ① MS-80IR+ Connected Device
- Select Select button
- 3 Import button
- 4 IR data in the pedal


This shows the IR number and name. Tap and hold an item to edit it.

- ⑤ Effect Screen button
- 6 Patch Memory Screen button
- (7) Editor Screen button
- 8 Import IR Screen button
- 9 News Screen button

Loading IR data




1 Tap the | | button.



2 Tap the button.



3. Tap the IR data to import.



4. The imported IR data will be added.

NOTE

Impulse response data in the following format can be loaded.

- · Format: WAV
- · Sampling frequency: 44.1-192 kHz

Edit the IR name



1 Tap and hold the IR data name.



2. Tap the button.



3. Edit the IR name.

4. Tap outside the window to end editing.

NOTE

- Valid characters and symbols: ! % & ' + , . = _ (space) A Z, a z, 0 9.
- Patch memory names can have a maximum of 20 characters.

Deleting IR data



1 Tap and hold the IR data name.



2. Tap the button.



3 Edit the IR name.

Using IRs

1 Tap the button in the navigation bar.



2 Tap the change button.



3. Tap the studio ambience.



4 Tap the Back button.



5 Tap "IR".



6 Select the IR you want to use and tap OK.



7. This changes the IR.



Tap to finish replacing effects.


NOTE

- Either one IR or one studio ambience can be used in each patch memory.
- When an IR is selected, the cabinet of the amp model will be bypassed.

Using the News Screen to review updated information



News Screen Overview



- ① MS-80|R+ Connected Device
- ② Open close button
- **3 Patch Memory Updates**

Tap this to view the contents. This shows information, including the availability of effects and patch memories.

- ④ Effect Screen button
- **5** Patch Memory Screen button
- 6 Editor Screen button
- 1 Import IR Screen button
- 8 News Screen button

Select and View News Updates



1 Tap the button in the navigation bar.



2 Tap the button to show the category contents.



3 Tap a news item to view it.


Download Patch Memory Updates



1 From the News screen, tap a news item to view it.



2. Tap the "Download" button to download the patch memories.



3. The patch memories are downloaded, extracted and saved into a Patch Group in the Pool.


Loading effects that are newly available into the unit



1 Tap the button in the navigation bar.



Tap the Effect Pool button. The Effect Pool appears.



Tap the next to the effect you want to load.



4. The effect is loaded onto the device and displayed in the Effects list.


NOTE

New

- An effect that has been downloaded from ZOOM but is new to the device.

Viewing a variety of information on the About Screen

About Screen Overview




- ① **〈Back** Back button
- 2 1.0.0 (20) App version
- ③ English 日本語 Language setting

The language setting can be changed by tapping these.

4 Connected device

This shows the name of the connected device and its firmware version.

Changing the language setting



1 Tap the MS-80IR+ button.



2 Open the About Screen, and tap a language.



3 This changes the language setting.



ZOOM CORPORATION 4-4-3 Kanda-surugadai, Chiyoda-ku,Tokyo 101-0062 Japan zoomcorp.com